# CamPocket Flash

Practical camera bag for digital equipment

Our CamPocket Flash is equipped with a thick, cushioned compartment to safely transport your digital equipment. The flap of the CamPocket Flash is closed with a Velcro fastening and allows for a quick retrieval of the camera. The two side flaps of the main compartment protect your digital equipment from above and prevent rain and spray water from entering the bag!
The CamPocket Flash offers lots of room in the attached front-side compartment for batteries, rechargeables, etc. The two integrated pockets can carry your memory cards.
It's for you to decide how you would like to carry your CamPocket Flash. The removable shoulder strap and the button-activated belt loop offers all options! CamPocket Flash is made of high-quality, robust artificial leather and available in the classic color black!

High-quality, robust artificial leather. cushioned main compartment for digital equipment, with cushioned side flaps to protect from above and prevent rain and spray water. flap with Velcro fastening. additional front pocket with room for batteries, rechargeables, etc., two integrated pockets with room for memory cards. belt loop. shoulder strap.

Art. Nr.: D7988K (black)
Material: Koskin
Weight: 0.09 kg / 0.2 lbs
Dimensions: 80 x 110 x 60 mm / 3.1 x 4.3 x 2.4 inch

DICOTA UK Ltd.
DICOTA House, Eastheath Avenue, Wokingham
RG41 2PR Berkshire

Phone: +44 - 870 - 382 1000
FAX: +44 - 870 - 382 1000
www.dicota.co.uk
sales@dicota.co.uk